




ICE-600 Installation and Operation Manual



Version: 3

Last Edited: 1/05/2026

InCharge Energy Inc.

All Rights Reserves. **This Manual May Be Subject to Change Without Notice**

<https://inchargeus.com/>

Service Hotline: 818-697-GOEV

Contents

1.) IMPORTANT SAFETY INSTRUCTIONS	5
1.1) Electrical Safety	5
1.2) Tools	5
1.3) Thunderstorm	6
1.4) Static Electricity	6
1.5) Short Circuit	6
1.6) Sharp Corners of Objects.....	6
1.7) Power Cable	6
1.8) Signal Cables	7
2.) General Product Description	8
2.1) Main Features	8
3.) General Characteristics	9
3.1) Technical Characteristics	9
3.2) Model Description.....	17
3.3) Standards	17
4.) Product Parts Presentation	19
5.) Installation	21
5.1) Safety and Compliance.....	21
5.2) Grounding Instructions	21
5.3) Unboxing and Visual Inspection	21
5.4) Assembly/Placing Instructions	21
5.4.1) Preparation of Concrete Foundation	22
5.4.2) Power Cabinet and Dispenser Installation.....	25
5.4.3) Power and Signal Cable Connections	31
5.4.4) Power Module Installation	39
5.5) Controller Setting	41
5.5.1) Address Settings	41
5.5.2) Resistance Setting	43
6.) Adding Cooling Liquid	45
6.1) Charging Dispenser Cold Source Description.....	45
6.2) Liquid Cooled Cable System	46

6.3) Adding Liquid Step	46
7.) Start Up.....	48
7.1) Verification and Inspection.....	48
7.2) Switch On	48
8.) Important Parameter Settings.....	51
8.1) System Communication Topology	51
8.2) System Internal LAN and CAN	52
8.3) Dispenser Parameter Setup.....	52
8.4 Power Cabinet Parameter Setup	56
8.5) Reset and Test	62
8.5.1) System Self Check.....	62
9.) Description of Relevant Parameters.....	63
10.) Power Distribution Strategy	65
10.1) Introduction to Power Nodes.....	65
10.2) Scenario 1: Increasing Charging Power	66
10.3) Scenario 2: Decreasing Charging Power	66
10.4) Scenario 3: Charging Initiated at Node Along the Power Path.....	69
11.) User Operation.....	71
11.1) Output Connector	71
11.1.1) CCS1 and NACS Connector	71
11.2) Operation Instructions	72
11.3) Ethernet and OCCP Setting.....	75
11.3.1) Connection Check	75
11.4) Network Setting	75
11.4.1) Router Set Up.....	75
11.4.2) Wireless Network Configuration	78
11.4.3) Wired Network Configuration	78
11.5) Charger Software Update.....	78
11.5.1) Upper Controller Update.....	78
11.5.2) Pilot Controller Update	80
Appendix 1) Engineering and Technical Parameters.....	81
Appendix 2) Power Cabinet and Dispenser Schematic.....	84

Appendix 3) System Electrical Connection Diagram	88
Appendix 4) Maintenance	90
1.) Maintenance Table.....	90
2.) Maintenance Operation	90
2.1) AC Input Main Breaker	90
2.2) Devices and Connection Points	91
2.3) AC SPD	94
2.4) Charging Plug	94
2.5 Cooling Fan and Filter Cotton	94
2.6) ESD.....	95
2.7) Alarm Information.....	96
Appendix 5) Error Codes and Possible Solutions	97
Appendix 6) Torque Table.....	106

1.) IMPORTANT SAFETY INSTRUCTIONS

- Please read the operating instructions and notes carefully before starting operation to prevent accidents. The "Caution, Attention, Warning, and Danger" statements in the products and product manual do not represent all safety matters to be observed and are intended to supplement various operational safety precautions.
- During the various operations of our products and equipment, it is necessary to comply with the relevant National Safety Regulations and strictly observe the precautions and special safety instructions for the relevant equipment provided by InCharge Energy.
- Any usage of water on the charger during a charge session or during idling is a safety hazard and prohibited.

1.1) Electrical Safety

 Danger	Since some parts of this power system are under high voltage during operation, direct or indirect contact can be fatal.
---	--

- It is necessary to comply with the relevant National Safety Regulations during the installation of the Portable DC Charger. Personnel who install and maintain this equipment must be qualified to work with high DC voltage up to 1000Vdc and 3-phase AC voltage up to 500Vac.
- It is strictly forbidden to wear watches, bracelets, bangles, rings and other conductive objects on the wrist during installation and maintenance.
- If there is water inside the DC Charger enclosure, AC power and DC connector must be disconnected immediately. During operation in a humid environment, water should be strictly prevented from entering the equipment.
- During installation, it is strictly forbidden to operate the DC Charger and an "Operation prohibited" signboard must be used.

 Danger	Construction operation of high voltage lines may cause fire or electric shock. The wiring area and the area where the line passes through for AC cables must comply with national and local regulations and norms. As this device utilizes high voltages do not attempt to install this equipment if you are not a qualified electrician.
---	--

1.2) Tools

 Warning	Special tools must be used during various operations involving high DC and AC voltages.
--	--

1.3) Thunderstorm

 Danger	It is strictly forbidden to carry out live installation and maintenance work during thunderstorms.
---	---

- A strong electromagnetic field will be produced in the atmosphere during a thunderstorm. Therefore, the equipment should be well grounded to avoid damage to the equipment due to lightning strikes.

1.4) Static Electricity

 Caution	Static electricity generated by the human body may damage electrostatic sensitive components on the circuit boards, such as the large-scale integrated circuit (IC), etc. Before handling any patch boards, circuit boards and IC chips, it is necessary to wear an anti-static wrist strap with the anti-static wrist strap wire connected to Ground to avoid damage to sensitive components due to static electricity.
--	---

1.5) Short Circuit

 Danger	During operation, it is strictly forbidden to short-circuit the positive and negative of the DC Charger DC distribution or short-circuit any DC distribution polarity to Ground. The DC Charger is a high voltage DC power supply, and short circuit may cause damage to the DC Charger and personal safety hazards.
---	---

- During work with High Voltage DC output, it is necessary to strictly check the polarity of cables and interface terminals.
- The space for DC power distribution work is compact, and attention should be paid to planning cable routing etc. before starting any installation work.
- Insulated tools must be used.
- During live work, attention should be paid to keeping hands, arms tools etc. away from live high voltage parts to avoid accidents.

1.6) Sharp Corners of Objects

 Warning	During the handling of equipment by hand, it is necessary to wear protective gloves to prevent injuries caused by sharp objects.
--	---

1.7) Power Cable

 Caution	Make sure that the cable label is correct before the connection of cables.
--	---

1.8) Signal Cables



Caution

Signal cables should be kept away from power cables, with a minimum distance of 100mm.

2.) General Product Description

The ICE-600 Split type-high power charger is specially designed for the Operator split and multi-EV charging point application with CCS/CHAdeMO/NACS standard. The Max output is 1000V/600kW when utilizing the 500A liquid cooled cable, and each Liquid Cooled charging connector can get max 600kW power.

The following ICE-600 split system consists of one 600KW Power Cabinet (ten channels output) and five Slim Line dispenser or ten Micro-Dispensers, including standard connector 125A(CHAdeMO)/200A(CCS&NACS)/300A(CCS&NACS) and liquid-cooled connector 500A(CCS&NACS).

2.1) Main Features

- The ICE-600 can fast charge all electric vehicles compliant with combined charging system (CCS) standards.
- IP55 for the Slim Line Dispenser, IP65 for the Micro Dispenser, and IP54 for the Power Cabinet with high protection and high reliability for harsh environment, -22°F ~ 122°F (-30°C~50°C) ambient temperature full power charging.
- Easily configure the output power up to 600kW and the output voltage up to 1000V.
- The battery charging state is displayed on the HMI and the charging cycle finishes by itself or can be interrupted by user command.
- The ICE-600 is user-friendly and safe. After user identification, it only requires coupling the charger's output plug in the EV for automatic starting if all safety features are accomplished.
- Full safety function with output contactor and fuse, ESD, SPD, leakage switch, insulation detector, and software logic for multiple protection.
- LAN and LTE wireless support, RFID authorization and Mobile App payment support.
- Optional CCS standard 500A liquid cooling charging connector in the Slim Line Dispenser
- Power transfer between up to 10 connectors to improve the charging operation efficiency.
- User friendly interface with tempered glass protective 7" TFT capacitive touch screen LCD for all Slim-Line Dispensers.

3.) General Characteristics

3.1) Technical Characteristics

The ICE-600 Split Power Cabinet and Dispenser technical characteristics are indicated in Table 3-1, Table 3-2, Table 3-3, Table 3-4, and Table 3-5. “N” means Natural cooling, “L” means Liquid cooling. The following is omitted:

Table 3-1: Power Cabinet (IDC600K3-FMR5) Technical Characteristics

Technical Data		Description	Remarks
Nominal Input	Phases/Lines	3 phases + P E (L1, L2, L3, + PE) WYE	
	Voltage	480/277 Vac (+/-10%)	
	Frequency	60Hz	
	Current	2*380A	
	Power	600kW	
	Power factor	≥0.99	
	System efficiency	≥ 94.5% (Full load)	
DC Output	Max power	600kW 300~1000V	
	Voltage range	150 ~ 1000Vdc	
	Current	10 outputs: Each output Max 500A	
	Dispenser support	5 dispensers / 10 charging connectors connection	
Auxiliary power Output (Single Phase to Dispensers)	Voltage	480Vac	
	Current	10A	
Cabinet	Dimensions(W*D*H)	41.33 x 45.28 x 86.62 (in) [1050×1150×2200 (mm)]	
	Weight	1521 lbs (720 kg) (excluding power module, power module is 34lbs (15.5kg.))	
	Protection Degree	NEMA 3R/IP54	
Networking method	Communication	Router 4G/5G (GSM, CDMA or LTE)	
Environmental conditions	Operating temperature ¹	-22°F ~ +122°F (-30°C ~ +50°C)	
	Transportation/storage temperature	-40°F ~ +158°F (-40°C ~ +70°C)	
	humidity	5%RH ~ 95%RH	
	Place of installation	Indoor / Outdoor	
	Altitude	6561 ft (2000m)	
	Sound Noise	≤65dB (nominal input/output power, the environment temperature is 77°F / 25°C.)	
	Atmospheric pressure	80KPa ~ 110Kpa (11.6 psi – 16.0 psi)	
	AC Input Overvoltage category	III	
	DC Output Overvoltage category	I	
	Protection class	Class I	
Note 1: The Charging Dispenser provides full output power up to 122°F (50°C), output power derating 5% / °C above 122°F (50°C).			

Table 3-2: Slim Line Dispenser (IDC500-LCD-UU2) Technical Characteristics

Technical Data		Description	Remarks
Nominal Input	Phases/Lines	(DC1+, DC1-) + (DC2+, DC2-) + PE	
	Voltage Range	Max 1000Vdc	
	Current	500A, 200A	
	Power	500kW, 200kW	
	System Efficiency	≥ 99% (Full load)	
DC Output CCS1(L)	Voltage	150 ~ 1000Vdc	
	Current	500A(L)	
	Nominal Power	500kW	
DC Output CCS1	Voltage	150 ~ 1000Vdc	
	Current	200A(N),	
	Nominal power	200kW	
Auxiliary Power Input	Voltage	480Vac	
	Current	0.6A	
Cabinet	Dimensions(W*D*H)	19.7*10.23*70.86 in (500*260*1800 (mm))	
	Weight	430 lbs. (195kg)	
	Protection Degree	NEMA 3S	
HMI and Command Unit	Local Interface	TFT Color touch display 7"	
	Communication	CAN, LAN	
	Protocol	OCPP1.6 specification	
Environmental Conditions	Operating Temperature ¹	-13°F ~ +122°F (-25°C ~ +50°C)	
	Transportation/Storage Temperature	-40°F ~ +158°F (-40°C ~ +70°C)	
	Humidity	5%RH ~ 95%RH	
	Place of Installation	Indoor / Outdoor ²	
	Altitude	6561.7 ft (2000m)	
	Sound Noise	≤60dB (nominal input/output power, the environment temperature is 77°F / 25°C.)	
	Atmospheric Pressure	80KPa ~ 110Kpa (11.6 psi – 16.0 psi)	
	Overvoltage Category	II	
	Protection Class	Class I	
Note 1: The Charging Dispenser provides full output power up to 122°F (50°C), output power derating 5% / °C above 122°F (50°C).			
Note 2: The protection degree of the Charging Dispenser is IP55.			

Table 3-3: Slim Line Dispenser (IDC300-FDC-UU2) Technical Characteristics

Technical Data		Description	Remarks
Nominal Input	Phases/Lines	(DC1+, DC1-) +(DC2+, DC2-) + PE	
	Voltage Range	Max 1000Vdc	
	Current	300A	
	Power	300kW	
	System Efficiency	≥ 99% (Full load)	
DC Output CCS1	Voltage	150 ~ 1000Vdc	
	Current	300A /300A	
	Nominal Power	300kW	
Auxiliary Power Input	Voltage	480Vdc	
	Current	0.6A	
Cabinet	Dimensions(W*D*H)	19.7*10.23*70.86 in (500*260*1800 (mm))	
	Weight	407.9 lbs. (185kg)	
	Protection Degree	NEMA 3S	
HMI and Command Unit	Local Interface	TFT Color touch display 7"	
	Communication	CAN, LAN	
	Protocol	OCPP1.6 specification	
Environmental Conditions	Operating Temperature ¹	-13°F ~ +122°F (-25°C~+50°C)	
	Transportation/Storage Temperature	-40°F ~ +158°F (-40°C~+70°C)	
	humidity	5%RH ~ 95%RH	
	Place of Installation	Indoor / Outdoor ²	
	Altitude	6561.7 ft (2000m)	
	Sound Noise	≤60dB (nominal input/output power, the environment temperature is 77°F / 25°C.)	
	Atmospheric Pressure	80KPa ~ 110Kpa (11.6 psi – 16.0 psi)	
	Overvoltage Category	II	
	Protection Class	Class I	
Note 1: The Charging Dispenser provides full output power up to 122°F (50°C), output power derating 5% / °C above 122°F (50°C).			
Note 2: The protection degree of the Charging Dispenser is IP55.			

Table 3-4: Slim Line Dispenser (IDC200-FDC-UU2) Technical Characteristics

Technical Data		Description	Remarks
Nominal Input	Phases/Lines	(DC1+, DC1-) + (DC2+, DC2-) + PE	
	Voltage Range	Max 1000Vdc	
	Current	200A	
	Power	200kW	
	System Efficiency	≥ 99% (Full load)	
DC Output CCS1	Voltage	150~1000Vdc	
	Current	200A / 200A	
	Nominal Power	200kW	
Auxiliary Power Input	Voltage	480Vdc	
	Current	0.6A	
Cabinet	Dimensions(W*D*H)	19.7*10.23*70.86 in (500*260*1800 (mm))	
	Weight	407.85 lbs. (185kg)	
	Protection Degree	NEMA 3S	
HMI and Command Unit	Local Interface	TFT Color touch display 7"	
	Communication	CAN, LAN	
	Protocol	OCPP1.6 specification	
Environmental Conditions	Operating Temperature ¹	-13°F ~ +122°F (-25°C ~ +50°C)	
	Transportation/Storage Temperature	-40°F ~ +185°F (-40°C ~ +70°C)	
	humidity	5%RH ~ 95%RH	
	Place of Installation	Indoor / Outdoor ²	
	Altitude	6561.68 ft (2000m)	
	Sound Noise	≤60dB (nominal input/output power, the environment temperature is (77 F) 25°C.)	
	Atmospheric Pressure	80KPa ~ 110Kpa (11.6 psi – 16.0 psi)	
	Overvoltage Category	II	
	Protection Class	Class I	
Note 1: The Charging Dispenser provides full output power up to 122°F (50°C), output power derating 5% / °C above 122°F (50°C).			
Note 2: The protection degree of the Charging Dispenser is IP55.			

Table 3-5: Slim Line Dispenser (IDC200-FDC-UC2) Technical Characteristics

Technical Data		Description	Remarks
Nominal Input	Phases/Lines	(DC1+, DC1-) +(DC2+, DC2-) + PE	
	Voltage Range	Max 1000Vdc ,500Vdc	
	Current	200A, 125A	
	Power	200kW ,62.5kW	
	System Efficiency	≥ 99% (Full load)	
DC Output CCS1	Voltage	150 ~ 1000Vdc	
	Current	200A	
	Nominal Power	200kW	
DC Output CHAdeMO	Voltage	150 ~ 500Vdc	
	Current	125A	
	Nominal Power	62.5kW	
Auxiliary Power Input	Voltage	480Vdc	
	Current	0.6A	
Cabinet	Dimensions(W*D*H)	19.7*10.23*70.86 in (500*260*1800 (mm))	
	Weight	407.85 lbs. (185kg)	
	Protection Degree	NEMA 3S	
HMI and Command Unit	Local Interface	TFT Color touch display 7"	
	Communication	CAN, LAN	
	Protocol	OCPP1.6 specification	
Environmental Conditions	Operating Temperature ¹	-13°F ~ +122°F (-25°C ~ +50°C)	
	Transportation/Storage Temperature	-40°F ~ +185°F (-40°C ~ +70°C)	
	humidity	5%RH ~ 95%RH	
	Place of Installation	Indoor / Outdoor ²	
	Altitude	6561.68 ft (2000m)	
	Sound Noise	≤60dB (nominal input/output power, the environment temperature is 77° (25°C)).	
	Atmospheric Pressure	80KPa ~ 110Kpa (11.6 psi – 16.0 psi)	
	Overvoltage Category	II	
	Protection Class	Class I	
Note 1: The Charging Dispenser provides full output power up to 122 F (50°C), output power derating 5% / °C above 122 F (50°C).			
Note 2: The protection degree of the Charging Dispenser is IP55.			

Table 3-6 Micro Dispenser (IDC400-FSW-U2) Technical Characteristics

Technical Data		Description	Remarks
Nominal Input	Phases/Lines	(DC+, DC-) +PE	
	Voltage Range	Max 1000Vdc	
	Current	400A	
	Power	400kW	
	System Efficiency	≥ 99% (Full load)	
DC Output CCS2	Voltage	150~1000Vdc	
	Current	400A	
	Nominal Power	400kW	
Auxiliary Power Input	Voltage	480Vac	
	Current	0.6A	
Cabinet	Dimensions(W*D*H)	30.04in x 9.45in x 16.34in (763*240*415 mm)	
	Weight	110lbs (50kg)	
	Protection Degree	IP65	
Command Unit	Local Interface	Status LED	
	Communication	CAN/Ethernet	
Environmental Conditions	Operating Temperature ¹	-22°F ~ +122°F (-30°C~+50°C)	
	Transportation/Storage Temperature	-40°F ~ +158°F (-40°C~+70°C)	
	humidity	5%RH~95%RH	
	Place of Installation	Indoor / Outdoor ²	
	Altitude	6561.68ft (2000m)	
	Sound Noise	≤55dB (nominal input/output power, the environment temperature is 25°C.)	
	Atmospheric Pressure	80KPa~110KPa	
	Overvoltage Category	III	
	Protection Class	Class I	
Note 1: The Charging Dispenser provides full output power up to 50°C, output power derating 5% / °C above 50°C.			
Note 2: The protection degree of the Charging Dispenser is IP55.			

Table 3-7 Micro Dispenser (IDC300-FSW-U2) Technical Characteristics

Technical Data		Description	Remarks
Nominal Input	Phases/Lines	(DC1+,DC1-)+PE	
	Voltage Range	Max 1000Vdc	
	Current	300A	
	Power	300kW	
	System Efficiency	≥ 99% (Full load)	
DC Output CCS1	Voltage	150~1000Vdc	
	Current	300A	
	Nominal power	300kW	
Auxiliary Power Input	Voltage	480Vac	
	Current	0.6A	
Cabinet	Dimensions(W*D*H)	30.04in x 9.45in x 16.34in (763*240*415 mm)	
	Weight	105.8lbs (48kg)	
	Protection Degree	IP65	
Command Unit	Local Interface	Status LED	
	Communication	CAN/Ethernet	
Environmental Conditions	Operating Temperature ¹	-22°F ~ +122°F (-30°C~+50°C)	
	Transportation/Storage Temperature	-40°F ~ +158°F (-40°C~+70°C)	
	Humidity	5%RH~95%RH	
	Place of Installation	Indoor / Outdoor ²	
	Altitude	6561.68ft (2000m)	
	Sound Noise	≤55dB (nominal input/output power, the environment temperature is 25°C.)	
	Atmospheric Pressure	80KPa~110KPa	
	Overvoltage Category	III	
	Protection Class	Class I	
Note 1: The Charging Dispenser provides full output power up to 50°C, output power derating 5% / °C above 50°C.			
Note 2: The protection degree of the Charging Dispenser is IP55.			

Table 3-8 Micro Dispenser (IDC200-FSW-U2) Technical Characteristics

Technical Data		Description	Remarks
Nominal Input	Phases/Lines	(DC1+,DC1-)+PE	
	Voltage Range	Max 1000Vdc	
	Current	200A	
	Power	200kW	
	System Efficiency	≥ 99% (Full load)	
DC Output CCS1	Voltage	150~1000Vdc	
	Current	200A	
	Nominal Power	200kW	
Auxiliary Power Input	Voltage	480Vac	
	Current	0.6A	
Cabinet	Dimensions(W*D*H)	30.04in x 9.45in x 16.34in (763*240*415 mm)	
	Weight	97lbs (44kg)	
	Protection Degree	IP65	
Command Unit	Communication	CAN,LAN	
	Communication	CAN/Ethernet	
Environmental Conditions	Operating Temperature ¹	-22°F ~ +122°F (-30°C~+50°C)	
	Transportation/Storage Temperature	-40°F ~ +158°F (-40°C~+70°C)	
	humidity	5%RH~95%RH	
	Place of Installation	Indoor / Outdoor ²	
	Altitude	6561.68ft (2000m)	
	Sound Noise	≤55dB (nominal input/output power, the environment temperature is 25°C.)	
	Atmospheric Pressure	80KPa~110KPa	
	Overvoltage Category	III	
	Protection Class	Class I	
Note 1: The Charging Dispenser provides full output power up to 50°C, output power derating 5% / °C above 50°C.			
Note 2: The protection degree of the Charging Dispenser is IP55.			

3.2) Model Description

Table 3-9: ICE-600 System Models

Model	Configuration	Remarks
IDC600K3-FMR5	10 charging connectors connection	600kW
IDC500-LDC-UU2	CCS1(L)+CCS1	500kW+200kW
IDC300-FDC-UU2	CCS1+CCS1	300kW+300kW
IDC200-FDC-UU2	CCS1+CCS1	200kW+200kW
IDC200-FDC-UC2	CCS1+CHAdeMO	200kW+200kW
IDC400-FSW-U2	CCS1	400kW
IDC300-FSW-U2	CCS1	300kW
IDC200-FSW-U2	CCS1	200kW

- The ICE-600 System supports multiple terminal combinations, and the above configuration table is the most classic configuration.
- For all non-standardized combinations, please refer to the InCharge Energy Spec Sheet for the ICE-600 Split System

3.3) Standards

The ICE-600 Split DC Charger complies with the following standards:

- **IEC 61851-1 2017:** Electric vehicle conductive charging system. Part 1: General Requirements
- **IEC 61851-23 2014:** Electric vehicle conductive charging system - Part 23: DC electric vehicle charging station
- **IEC 61851-24 2014:** Electric vehicle conductive charging system - Part 24: Digital communication between a DC EV charging station and an electric vehicle for control of DC charging
- **EN 61851-1 2019:** Electric vehicle conductive charging system. Part 1: General Requirements
- **EN 61851-23 2014:** Electric vehicle conductive charging system - Part 23: DC electric vehicle charging station
- **EN 61851-24 2014:** Electric vehicle conductive charging system - Part 24: Digital communication between a DC EV charging station and an electric vehicle for control of DC charging
- **UL 2202:** Standard for Safety for Electric Vehicle (EV) Charging System Equipment
- **CSA 22.2:** Power Conversion Equipment
- **UL 2202:2009 R2.18:** STANDARD FOR SAFETY Electric Vehicle (EV) Charging System Equipment
- **UL 2231-2 R08.16:** STANDARD FOR SAFETY Personnel Protection Systems for Electric Vehicle (EV) Supply Circuits: General Requirements

- **UL 2231-1 R08.16:** STANDARD FOR SAFETY Personnel Protection Systems for Electric Vehicle (EV) Supply Circuits: Requirements for Protection Devicesfor Use in Charging System.

4.) Product Parts Presentation

The ICE-600 Split DC Charging System is composed of Power Cabinet and Charging Dispensers. The System can be installed indoors or outdoors. However, when installed outdoors and used during inclement weather (snow/rain), caution should be used when performing charging as water can reach the charging connector.

The ICE-600 separate DC charging system series of fast DC chargers have various possible output combinations, as shown in Figures 4.1, 4.2, and 4.3:



Figure 4.1 External View (Example: 10 connectors / 5 Slimline Dispenser system)




Figure 4.2 system Connection Diagram with all Slim Line Dispenser




Figure 4.3 System Connection Diagram with All Micro Dispenser

5.) Installation

5.1) Safety and Compliance

The working voltage and current inside the charging system is very high. The following rules should always be observed to ensure personal safety:

- Only personnel who have received training for and fully mastered the knowledge of the charging system can complete installation. During installation, always observe the safety precautions mentioned in this document and all relevant National Safety Regulations.
- It is necessary to make sure that the charging system DC output is disconnected in case of operation inside the charging system. The main inputs of the charging system must also be disconnected.

5.2) Grounding Instructions

An equipment grounding conductor, or a grounded, metal, and permanent wiring system is required for the ICE-600 charger connection. This should be run with circuit conductors and connected to the equipment grounding bar or lead on the ICE-600 charger.

5.3) Unboxing and Visual Inspection

- Check if the exterior packaging has been damaged by mechanical impacts or any accidents during transportation.
- If applicable, check that the exterior panels of the ICE-600 are without fault.
- Check if the interior of the Quick Charger Station is clean.
- Check if the door of the Quick Charger Station is working properly.
- Check for a proper Quick Charger Station protective ground connection point, which should be interconnected with the low voltage switchboard ground connection during the installation.

5.4) Assembly/Placing Instructions

- As shown in Figures 5.2 and 5.3, the concrete foundation should be made, and the height of the base should not be less than 7.9 in (200 mm).
- It is recommended to reserve a Φ 90 plastic pipe at the cable entrance, and the height of the pipe extending out of the foundation horizontal plane shall not be more than 3.15 in (80mm).
- As shown in Figure 5.2, mark the installation holes of four M12 expansion bolts on the concrete foundation.
- Drill 4 holes on the concrete foundation, select the hammer drill bit of Φ 16mm type, and use the percussion drill to drill the holes perpendicular to the ground at the above marked hole position, with the drilling depth of 2.36 ~ 3.15 in (60mm ~ 80mm).

- Use four M12 × 60 expansion bolts equipped with attached accessories, slightly tighten the bolts, vertically put them into the hole, and knock them with a rubber hammer until all the expansion pipes enter the installation hole.
- Screw off the bolt, spring pad and flat pad in turn counterclockwise.





Figure 5.1 Expansion Bolt Fixing of Concrete Foundation

5.4.1) Preparation of Concrete Foundation






Figure 5.2 Power Cabinet Concrete Foundation View






Figure 5.3 Slim Line Dispenser Concrete Foundation View

5.4.2) Power Cabinet and Dispenser Installation

5.4.2.1) Power Cabinet Installation

- The protective covers on both sides of the steel base of the cabinet can be removed, and the cabinet can be transported to the concrete foundation by forklift.
- Align the installation hole of the cabinet base and fix the cabinet on the concrete foundation with M12*60 expansion bolts at a torque value of 28.40 ft-lbs




Figure 5.4 Power Cabinet Installation View




Figure 5.5 Power Cabinet Top View

5.4.2.2) Slim Line Dispenser Installation




Figure 5.6 Charging Dispenser Installation View




Figure 5.7 Charging Dispenser Top View

5.4.2.3) Micro Dispenser Wall Mount Installation




Figure 5.8 Micro Dispenser Mounted on Wall




Figure 5.8.1 Micro Dispenser Wall Mount Bracket

- Drill holes into the wall based on the dimensions of the bracket shown in figure 5.8. Secure the bracket onto the wall with four M10*60 bolts and torque them down to the specified value.




Figure 5.8.2 Micro Dispenser adapter brackets

- Secure the two brackets onto the back of the Micro Dispenser utilizing four M6*12 bolts.




Figure 5.8.3 Micro Dispenser attachment

- Lift and place the micro dispenser onto the wall mount bracket. Once placed, secure in place with four M5*12 bolts.

5.4.2.4) Micro Dispenser Overhead Mount Installation




Figure 5.9 Dispenser Mounted on A Steel Frame or Gantry




Figure 5.9.1 Micro Dispenser Gantry Mount Bracket

- Drill holes into the wall based on the dimensions of the bracket shown in figure 5.9. Secure the bracket onto the wall with four M10*60 bolts and torque them down to the specified value.




Figure 5.9.2 Micro Dispenser adapter brackets

- Secure the two brackets onto the back of the Micro Dispenser utilizing four M6*12 bolts.




Figure 5.10 Micro Dispenser Gantry Mount

- Installation on angled overhead support : As shown in the figure 5.11 : Firstly, combined with the slope of the parking gantry, adjust the installation support angle so that the installed terminal is perpendicular to the ground. (Installation supports four angle adjustments: 0 ° , 10 ° , 20 ° , and 30 ° , to adapt to different gantry slopes). Then, use the combination bolts to install the Installing support in the corresponding

position on the Parking sheet. Simultaneously install the Cabinet wall pendant on the charging dispenser. Finally, affix the charging dispenser onto the Installing Support.




Figure 5.11 Diagram of Adjustment Angle of The Installation Plate

5.4.3) Power and Signal Cable Connections

Notes: System cable connection see Appendix 3 for the electrical connection of the 600kW Split System. The communication distance between the system cabinets shall be less than 50m.

5.4.3.1) Connection Power Cabinet AC Input Cable

- Power Cabinet AC input wiring: two sets of AC input, using four-core cables, 3 phases + protective grounding as shown in Figure 5.12




Figure 5.12 Power Cabinet AC Input Cable

Note:

- Neutral Wiring is Optional and not Required


Table 5-1 Selection of AC Input Cable for Power Cabinet

Table 5- Selection of AC Input Cables for Power Cabinet						
NO.	The section for AC feed cables	Amperage at 480Vac	Max. Power of charger	Specification of terminal screw	Reserved length inside cabinet	Wiring diagram
1	(AC INPUT1) 3*240mm2+2*120mm2	380A	600kW	L1/L2/L3/ is M12 PE is M10	31.5 in (0.8m)	Figure 5.8
	(AC INPUT2) 3*240mm2+2*120mm2	380A		L1/L2/L3/ is M12 PE is M10	31.5 in (0.8m)	
Aluminum conductors may be used in place of copper conductors. Ensure to properly size and install per National Electrical Code/Local Codes						

Notes:

- The AC feed power cables should be no less than 90°C (194 F) temperature resistant grade.
- The protective MCCB must be installed on the customer's distribution cabinet, and the upper MCCB capacity shall not be less than 1.25 times the input current.

- It is recommended that the upper MCCB should not be equipped with RCD function.
- This system is to be connected to a grounded, metal, permanent wiring system; or an equipment-grounding conductor is to be run with circuit conductors and connected to equipment-grounding terminal or lead on battery charger.
- **Before electrical connection, all switches shall be placed in the disconnection position.**



1	2QFP	Auxiliary Power 2 for Power Cube
2	1QFP	Auxiliary Power 1 for Power Cube
3	3QFP	Auxiliary Power for Dispenser
4	2QF	AC Input MCCB 2
5	1QF	AC Input MCCB 1
6	2SPD	AC SPD 2
7	1SPD	AC SPD 1
8	ESD	Emergency Shutdown Device
9	LED	Light emitting diode

Figure 5.13 Power Cabinet AC Input

5.4.3.2 Connection of Power Cables

- It is recommended to select the connection cable between the Power Cube and the Dispensers according to the requirements in Table 5-2. Connect the power cable between the power Cabinet and the Dispenser as shown in the following diagram 5.14 and diagrams 5.15 and 5.16.

Table 5-2 Selection of Cables from Power Cabinet to Dispenser

NO	Name of Connector	The section for DC feed cables	Amperage	Specification of terminal screw	Reserved length Power Cabinet	Reserved length Dispenser	Wiring diagram
1	Dispenser A DC Input	2*0.37 in2(240mm2)	500A,1000V	(DC1+, DC1-) is M10	1m (39.37 in)	43.31 in (1.1m)	Figure 5.14 or 5.15
2		2*0.11 in2 (70mm2)	200A,1000V	(DC2+, DC2-) is M10	1m (39.37 in)	43.31 in (1.1m)	
3		0.78 in2 (50mm2)	/	PE is M8	0.5m (19.68 in)	43.31 in (1.1m)	
4	Dispenser B DC Input	2*0.15 in2 (95mm2)	300A,1000V	(DC1+, DC1-) is M10	1m (39.37 in)	43.31 in (1.1m)	Figure 5.14 or 5.15
5		2*0.15 in2 (95mm2)	300A,1000V	(DC2+, DC2-) is M10	1m (39.37 in)	43.31 in (1.1m)	
6		0.78 in2 (50mm2)	/	PE is M8	0.5m (19.68 in)	43.31 in (1.1m)	
7	Dispenser C DC Input	2*0.11 in2 (70mm2)	200A,1000V	(DC5+, DC5-) is M10	1m (39.37 in)	43.31 in (1.1m)	Figure 5.14 or 4.15
8		2*0.11 in2 (70mm2)	200A,1000V	(DC6+, DC6-) is M10	1m (39.37 in)	43.31 in (1.1m)	
9		0.78 in2 (50mm2)	/	PE is M8	0.5m (19.68 in)	43.31 in (1.1m)	
10	Dispenser D DC Input	2*0.11 in2 (70mm2)	200A,1000V	(DC1+, DC1-) is M10	1m (39.37 in)	43.31 in (1.1m)	Figure 5.14 or 5.15
11		2* 0.78 in2 (50mm2)	125A,500V	(DC2+, DC2-) is M10	1m (39.37 in)	43.31 in (1.1m)	
12		0.78 in2 (50mm2)	/	PE is M8	0.5m (19.68 in)	43.31 in (1.1m)	
13	Dispenser E	2*120mm2	400A,1000V	(DC1+,DC1-)is M10	1m	1.1m	Figure 5.16
14	DC Input	50mm2	/	PE is M8	0.5m	1.1m	
15	Dispenser F	2*95mm2	300A,1000V	(DC1+,DC1-)is M10	1m	1.1m	Figure 5.16
16	DC Input	50mm2	/	PE is M8	0.5m	1.1m	
17	Dispenser G	2*70mm2	200A,1000V	(DC1+,DC1-)is M10	1m	1.1m	Figure 5.16
18	DC Input	50mm2	/	PE is M8	0.5m	1.1m	
19	Auxiliary power input of Charging Dispenser	2*0.0038 in2 (2.5mm2)	1.2A,480V	L1/L2 is E2510	1m (39.37 in)	1m (39.37 in)	Figure 5.17, 5.18, 5.21, or 5.24
20	Can communication cable	UL2464 22AWG 2C With shielding	/	CANH/CANL is E0510	1m (39.37 in)	1m (39.37 in)	Figure 5.17, 5.18, 5.20 or 5.22
21	LAN communication of Charging Dispenser	2*CAT6 shielded network cable	/	Upper and Pilot controller LAN is RJ45	3m (118.11 in)	78.74 in (2m)	Figure 5.17, 5.18, 5.19 or 5.23





Figure 5.14 Power Cabinet DC Output



1	LED	Light emitting diode
2	LCD	Touch screen
3	CCS1/NACS/CHAdemo	Charging Connector
4	DC	DC input copper bar
5	J1	Auxiliary power supply
6	ETH	Network interface
7	J2	Communication signal connector
8	Pump	Liquid Cooled Cable Oil Pump

Figure 5.15 Dispenser DC Output

Micro Dispenser E, F, G




Figure 5.16 Dispenser DC Input

5.4.3.3) Connection of Signal Cables (Slim Line Dispenser)

- The Signal and Auxiliary power connection between Power Cabinet and the Slim Line Dispenser are shown in Figure 5.17 and Cable selection according to table 5-2.




Figure 5.17 Power Cabinet auxiliary power supply and signal cable connection diagram for Slim Line Dispenser.

5.4.3.4) Connection of Signal Cables (Micro Dispenser)

- The Signal and Auxiliary power connection between Power Cabinet and the Micro Dispenser are shown in Figure 5.18 and Cable selection according to table 5-2.




Figure 5.18 Power Cube auxiliary power supply and signal cable connection diagram

5.4.3.5) Connection of Network Cable (Slim Line Dispenser)




Figure 4.14 Network cable connection diagram

Figure 5.19 Network cable connection diagram for Slim Line Dispensers

5.4.3.6) Connection of Signal Cable (Slim Line Dispenser)




Figure 5.20 Signal cable connection diagram for Slim Line Dispensers

5.4.3.7) Auxiliary Power Cable Connection (Slim Line Dispenser)




Figure 5.21 Power Cabinet and Dispenser Auxiliary power connection diagram for Slim Line Dispensers

5.4.3.8) Connection of Signal Cable (Micro Dispenser)




Figure 5.22 Signal cable connection diagram for Micro Dispenser

5.4.3.9) Connection of Signal Cable (Micro Dispenser)




Figure 5.23 Network cable connection diagram for Micro Dispenser

5.4.3.10) Auxiliary Power Cable Connection (Micro Dispenser)





Figure 5.24 Power Cabinet and Dispenser Auxiliary power connection diagram for Micro Dispensers

5.4.4) Power Module Installation

- Slim Line Dispenser: For the ICE-600 split type ten connector/five dispenser system, the charging modules are divided into ten sets of modules. Dispenser A utilizes two sets of modules, with dialing numbers of 1 and 2 respectively; Dispenser B utilizes two sets of modules, with dialing numbers of 3 and 4 respectively; Dispenser C utilizes two sets of modules, with dialing codes of 5 and 6 respectively; Dispenser D utilizes two sets of modules, with dialing of 7 and 8 respectively; Dispenser E utilizes two sets of modules, with dialing of 9 and 10 respectively.
- Micro Dispenser: For the ICE-600 split type ten connector/ten dispenser system, the charging modules are divided into ten sets of modules. Dispenser A utilizes one set of modules, with dialing numbers of 1; Dispenser B utilizes one set of modules, with

dialing numbers of 2; Dispenser C utilizes one set of modules, with dialing codes of 3; etc. Each Dispenser will be addressed its own set of modules in order.

- As shown in the following figure 5.25 and 5.26 below:



Dial Switch, Left High, Right Low

Figure 5.25 Front view of Power Module




Figure 5.26 Power Cabinet front view of Power Modules


 Caution	The Power Module is heavy. Please be careful when moving the module. If the system is configured to less than 600kW output power, then some power modules will be removed. The empty power module slots must be covered by blanking plates. Otherwise, the system thermal management will not function correctly.
---	---

5.5) Controller Setting


Notes: Power Cabinet and Charging Dispenser Controller address settings. See Appendix 2 for the electrical connection of the 600kW split system.

5.5.1) Address Settings


- The ADD of the controller marked as "IMSU-X" in the Power Cabinet does not require an address to be set.
- The dispensers are addressed in a series layout, and the first dispenser in the line will be Dispenser A. Complete the address settings below. Once complete, make your way to the next dispenser and set the address accordingly. Follow this address setting process for all remaining dispensers in the system.
- The ADD of the controller labeled "IMSU-X" in Dispenser A should be set to 0, pin1 set to OFF, pin2 set to OFF, pin3 set to OFF, and pin4 set to OFF.




- The ADD of the controller labeled "IMSU-X" in Dispenser B should be set to 1, pin1 set to OFF, pin2 set to OFF, pin3 set to OFF, and pin4 set to ON.




- The ADD of the controller labeled "IMSU-X" in Dispenser C should be set to 2, pin1 set to OFF, pin2 set to OFF, pin3 set to ON, and pin4 set to OFF.




- The ADD of the controller labeled "IMSU-X" in Dispenser D should be set to 3, pin1 set to OFF, pin2 set to OFF, pin3 set to ON, and pin4 set to ON.




- The ADD of the controller labeled " IMSU-X " in the Dispenser E should be set to 4, pin1 is set to OFF, pin2 is set to ON, pin3 is set to OFF, pin4 is set to OFF




- The ADD of the controller labeled " IMSU-X " in the Dispenser F should be set to 5, pin1 is set to OFF, pin2 is set to ON, pin3 is set to OFF, pin4 is set to ON.




- The ADD of the controller labeled " IMSU-X " in the Dispenser G should be set to 6, pin1 is set to OFF, pin2 is set to ON, pin3 is set to ON, pin4 is set to OFF.




- The ADD of the controller labeled " IMSU-X " in the Dispenser H should be set to 7, pin1 is set to OFF, pin2 is set to ON, pin3 is set to ON, pin4 is set to ON.



- The ADD of the controller labeled " IMSU-X " in the Dispenser I should be set to 8, pin1 is set to ON, pin2 is set to OFF, pin3 is set to OFF, pin4 is set to OFF.



- The ADD of the controller labeled " IMSU-X " in the Dispenser J should be set to 9, pin1 is set to ON, pin2 is set to OFF, pin3 is set to OFF, pin4 is set to ON.



5.5.2) Resistance Setting

- The CAN communication line between the Dispensers is connected in a hand in hand manner. A 120 Ω resistor needs to be retained on the monitoring IMSU-X-CAN3 of the last Dispenser D, while the remaining CAN3 resistors of Dispenser A, Dispenser B, and Dispenser C are removed to ensure that the CAN bus is 60 Ω .
- Remove the CAN3 resistors from four Dispensers A, B, C, D. As shown in Figure 5.27. Move the jumper to pins 2 and 3.




Figure 5.27 Resistance Setting Diagram

- Dispenser E requires the jumper to be placed on pins 1 and 2. As shown in Figure 5.28:




Figure 5.28 Resistance Setting Diagram

- Controller Dialing and resistance settings are shown in figure 5.29

Note: The CAN resistor jumper on pins 1 & 2 is installed on the last dispenser in the system. All other dispensers, the jumpers must be set on pins 2 & 3.




Figure 5.29 Address setting diagram

6.) Adding Cooling Liquid

6.1) Charging Dispenser Cold Source Description

- Liquid cooling system by the pump, reservoir, hoses, radiator, fan, pressure sensors, temperature sensors, liquid level alarm switch, drive controller, etc., As shown in Figure 6.1 below




Figure 6.1 Schematic diagram of cold source of the Slim Line Dispenser

6.2) Liquid Cooled Cable System

- The cable system consists of connector no.1, cable no.2, cable fixture no.3, terminal to power supply no.4, ground wire no.5, pipes for coolant no.6, sensor and communication wires no.7. The cable system is fully assembled and only must be connected to the charging station. As shown in Figure 6.2 below:




Figure 6.2 Schematic diagram of CCS1 liquid cooling connector

Notes

- There is a coolant pipe inside the liquid cooling connector. Users should ensure the minimum bending radius during charging $R > 10D$.
- CCS liquid cooling connector: $10D = 10 \times 1.2 = 12\text{in}$ ($10 \times 31.5 = 315\text{mm}$)
- GBT liquid cooling connector: $10D = 10 \times 1.6 = 16\text{in}$ ($10 \times 40 = 400\text{mm}$)

6.3) Adding Liquid Step

- Prepare a funnel and a 5L (1.32 Gal) measuring cup, 6L (1.60 Gal) of silicone oil specified by the manufacturer.
 - Note: Huber silicone oil shall be used for CCS connector and 8025 Coolant oil shall be used for GBT liquid cooling connector. The two must not be mixed!



- Remove the fixing screws of the protective filter on the front of the charging terminal 6pcs*M4.




Figure 6.3 Front view of Dispenser

- Open the cooling source filling port bolt.
- Introduce 2200mL (0.60 Gal) of silicone oil into the measuring cup, add it to the fuel tank twice, add 1600mL to the fuel tank for the first time (always observe the oil level and stop adding liquid when the oil is below the high liquid level visual window), and tighten the filling port bolt.
- Once the system is powered on (see section 7), conduct the manual running of the liquid cooling system in each dispenser (as applicable). Perform the liquid cooling system oil circuit test. Observe that there is no leakage in the oil circuit and the oil pressure of the charging interface is normal (about 0.6~0.7Mpa). Ensure the oil temperature of connector is normal and it runs stably for 30 minutes. After the oil level is lower than the high liquid level sight window, open the cold source liquid filling port and add approximately 600mL (0.16 Gal) of silicone oil to the oil tank until you can see the level in the sight window. Ensure the oil level does not go above the high liquid level sight window. Tighten the liquid filling port cap. Turn off oil pump.
- **Note 1:** See Section 7 (START-UP) for powering on system. See Section 8 for Charging Dispenser startup and touch screen parameter settings.
 - **Note:** If the oil pressure is too low or 0 during the operation of the oil pump, please see if the oil pipe connection is in place or inspect for any kinked piping.
- Finally, install the protective filter on the front of the Charging Dispenser, and the cold source system is filled with liquid.


7.) Start Up

7.1) Verification and Inspection

- Check if the bolts of the AC and protective ground cables of the ICE-600 are correctly tightened to the specified torque
- Check the resistance between the ICE-600 protective ground and the low voltage switchboard ground connection; the value must be according to local codes.
- Grid AC with L1/L2/L3/PE wiring or DC+/DC-/PE wiring for DC input.
- Power modules panel address setting is correct.
- Before switching ON all the fuses and circuit breakers, check the supply voltage between lines: it must be $480V \pm 10\%$ 60Hz.

7.2) Switch On


- Grid AC input connection wiring (L1, L2, L3, PE) to Main breaker
- Check all switches in the system are off (System Main breaker, AC output breaker, Aux power input breaker).
- Install the power modules as needed. If there is an empty slot, a blank plate must be installed to cover the empty slot for proper air flow inside the Power Cabinet.
- Turn AC Grid power on, then check input voltages at the Power Cabinet. Verify voltages are 480VAC Phase to Phase and 277VAC Phase to PE. If voltages are not within tolerance, stop and verify system is fed with a 480/277VAC WYE electrical feed, check all input connections and wiring and try again.
- First switch on the auxiliary power switch 1QFP, 2QFP and 3QFPk of the Power Cabinet, as shown in Figure 7.1



1	2QFP	Auxiliary Power 2 for Power Cube
2	1QFP	Auxiliary Power 1 for Power Cube
3	3QFP	Auxiliary Power for Dispenser
4	2QF	AC Input MCCB 2
5	1QF	AC Input MCCB 1
6	2SPD	AC SPD 2
7	1SPD	AC SPD 1
8	ESD	Emergency Shutdown Device
9	LED	Light emitting diode

Figure 7.1 Front view of Power Cabinet

- Next, switch on the auxiliary power switches QFP of charging Dispensers A through E (or A through J if using all Micro-Dispensers) respectively, as shown in Figure 7.2



1	QFP	AC Input for Auxiliary Power
---	-----	------------------------------

- Check all controllers and meters, LCD and LED.
- Switch the main circuit breakers 1QF and 2QF of the Power Cabinet system to enable the power module input., as shown in Figure 7.1.
- Finally check the alarm from the front panel LED and Display for information about the system. If all parameters are set properly and all self-checks are clear, no alarms should be present. If alarms are present, address as needed to clear all alarms.


Note:

- Please add liquid to the cold source system of the charging terminal before starting the system, otherwise the cold source system will fail to start properly due to improper oil level. The cold source system needs to be tested at the first power-on, and silicone oil is added to a reasonable position. (See Chapter 6 ADD LIQUID)

8.) Important Parameter Settings


Note: Before configuring any of the system components. Go to section 11.4.1 for the router set up procedure.

8.1) System Communication Topology



- Between CCU-Pilot and PCU-Pilot Session, through CAN communication way. CCU-Pilot is client and PCU-Pilot is server. The function of this session is for the CCU to request the required power for the vehicle from the PCU during the charging process. These messages include heartbeat, status, requirements, faults, etc.
- Between CCU-Pilot and Dispenser-Upper Session. through Ethernet TCP to communicate. CCU-Pilot is client and Dispenser-Upper is server. The function of this session is to exchange charging information and set parameters. CCU sends charging information to Dispenser-Upper, which processes the data and displays it on the screen, web, and OCPP Server.
- Between Dispenser-Upper and PC-Upper Session. Through ethernet TCP to communicate. Dispenser-Upper is client and PC-Upper is server. The function of this session is to exchange charging information and set parameters. Dispenser-Upper sends charging information to PC-Upper, which processes the data for convenient centralized maintenance and access to OCPP server.
- Between PCU and PC-Upper Session. through Ethernet TCP to communicate. PCU is client and PC-Upper is server. The function of this session is for PCU to transmit information about the power cabinet to PC-Upper, including power module information, PDU information, input/output information, thermal management information, etc.; PC Upper can also set parameters to PCU.

8.2) System Internal LAN and CAN




- The power cabinet and dispensers communicate through Ethernet and CAN bus, as shown in the figure above. The blue line is the Ethernet cable, and the brown line is the CAN cable. Each dispenser has an independent network address and CAN address. The network address of the dispenser upper (IMMU2) is determined using the 'Charger Type' parameter on the HMI, while the network address and CAN address of the dispenser pilot (IMSU-X) are determined using dialing.

8.3) Dispenser Parameter Setup

- The parameter settings of the dispensers are basically the same as those of the integrated charger. The dispenser only has some unique parameter settings for the split charging system; Therefore, here we only introduce some parameters related to split charging system dispenser. Please refer to Document <IMMU2 Upper Controller Maintenance Guideline> for the remaining parameter settings.
- Notice: The parameters introduced below are essential to set after the system is installed.
- Login to the screen of the dispenser using the Root Login.

1. “Param Set” -> “Charger System” -> “Charger Type”




Index	Parameter Name	Parameter Value
1	Time Zone	+00:00
2	System DateTime(UTC+0)	2024-08-29 11:23:52
3	Network Setting	(Click for Detail...)
4	Charger Type	Split Dispenser-1
5	Dispenser Access OCPP Method	LAN with 4G Router
6	Split System Internal Network Segment	192.168.1.XX

Parameter Name: Charger Type
Parameter Value: Split Dispenser-1

OK
Cancel

- The default value of parameter Charger Type is Integrated, and the split system dispenser needs to be set to the corresponding value, such as Dispenser-1 being set to 'Split Dispenser-1', Dispenser-2 being set to 'Split Dispenser-2', Dispenser-3 being set to 'Split Dispenser-3', and so on. This parameter is associated with the IP address of Upper ETH1, which will fix the IP address of ETH1 to 192.168.1.201~192.168.1.210. After setting this parameter, it needs to be restarted to take effect.

2. “Param Set” -> “Charger System” -> “Dispenser Access OCPP Method”



Index	Parameter Name	Parameter Value
1	Time Zone	+00:00
2	System DateTime(UTC+0)	2024-08-29 11:39:01
3	Network Setting	(Click for Detail...)
4	Charger Type	Split Dispenser-1
5	Dispenser Access OCPP Method	LAN with 4G Router
6	Split System Internal Network Segment	192.168.1.XX

None
LAN with 4G Router
Independent 4G router

This parameter is a setting item for the dispenser access OCPP server method. It can choose from the above three values; the default value is LAN with 4G Router. The meaning of the three values are:


- **None:** The dispenser does not access OCPP Server, and the split charging system is connected to OCPP server through PC-Upper Controller.
- **LAN with 4G Router:** The dispenser accesses the OCPP server through a 4G router connected to the system LAN switch located in the PC. Please ensure that the IP address of the 4G router connected to the power cabinet switch is 192.168.1.1.
- **Independent 4G Router:** Each dispenser uses an independent 4G router to access the OCPP server. In this condition, the independent 4G Router will occupy the ETH1 of the Upper, so the network cable from the dispenser to the power cabinet does not need to be connected.
 - NOTE: To connect a Dispenser to an OCPP Server, 'OCPP Server End URL' and 'Charger ID' settings also should be set.

3. "Param Set" ->"Charger System" ->"Split System Internal Network Segment"

Active Alarm Detailed Info Param Set Manual Ctrl Charge Rec

Charger System

Index	Parameter Name	Parameter Value
1	Time Zone	+00:00
2	System DateTime(UTC+0)	2024-09-05 01:42:27
3	Network Setting	(Click for Detail...)
4	Charger Type	Split Dispenser-1
5	Dispensr Access OCPP Method	LAN with 4G Router
6	Split System Internal Network Segment	192.168.1.XX



- This parameter is the network segment used by the dispenser to access the system LAN. The default value is "192.168.1. XX", and the other value is used by other systems.

4. "Param Set" ->"Charger System" ->"CCU Work Mode"

Active Alarm Detailed Info Param Set Manual Ctrl Charge Rec

CCU Group

Index	Parameter Name	Parameter Value
1	Charger/CCU Specific Settings	(Click for Detail...)
2	Smart Charge Accuracy Compensation	0%
3	AC Main input includes AC connector input	Yes
4	CCU Work Mode	Standalone TCP
5	Is the Liquid Module Installed	No
6	Liquid-cooled Connector Installing type	Not Installed

Standalone RS232

Standalone TCP

Ring Address #1

Ring Address #2

Ring Address #3

Ring Address #4

- This parameter is the communication method between the dispenser upper controller and the pilot controller. The default value is Standalone TCP, be careful not to modify the default value.


5. "Param Set" ->"Charger System" ->"PC DC Output Number of Connector-A/B"

◀ CCU Group ▶

Index	Parameter Name	Parameter Value
7	PowerCabinet System Fan Startup Speed	50%
8	PowerCabinet System Fan Full Speed	50%
9	Trickle Charge Start SOC	101%
10	PC DC Output Number of Connector-A	1
11	PC DC Output Number of Connector-B	2
12	PLC&CHAdemo log grab type	RS232(for Gridwiz&RNL)


▲
2/4
▼

- These parameters are the DC output numbers of the power cabinet corresponding to the dispenser connectors A/B.



- In the above example, Dispenser-1 connector A is connected to power cabinet DC-1 and connector B is connected to power cabinet DC-3. Dispenser-2 connector A is connected to power cabinet DC-5 and connector B is connected to power cabinet DC-7. So, dispenser-1 should be set as 1 and 3, dispenser-2 should be set as 5 and 7.
 - If the dispenser installed is a Micro-Dispenser, only the parameter of connector-A should be set to the proper PC output, and connector-B should be set to 0.
 - Verify for all dispensers the power cabinet output connected to the dispenser input for each connector and assign accordingly.
- See Section 9 for a full list of configuration settings and appropriate values/ranges.

8.4 Power Cabinet Parameter Setup



192.168.1.100/login

Charger Web Management System

Login to admin page English


ROOT

...

root_key: [Select a file](#)

OK

- The Power Cabinet Upper Controller does not have an HMI, so a webpage is used to access the power cabinet upper controller for parameter settings and information display.
- To access this, use an Ethernet cable and connect a laptop to The ETH2 port on the Upper Controller. Open a web browser and go to IP address 192.168.99.100. Login using the ROOT access password and root key file.



ROOT

Charger System

Quick Settings

Detailed Info

Param Set

Manual Ctrl

Data Service

Firmware Management

User Management

Quit

Charger System

CCU Group

Charging Gun

Card Reader

PCU

Rectifier Grps

AC Cabinet

Split System Internal Network Segment	192.168.1.XX	Edit
Power Cabinet Access OCPP Enable	Enabled	Edit
Charger ID	075510011001480	Edit
OCPP Server End URL	ws://192.168.1.35:6019	Edit
Security Profile	Profile 0	Edit
Language Selection Mode	All	Edit
Dispenser Installed Total	12	Edit
Charging Gun Installed Total	12	Edit
Dispenser Type	Standard	Edit
LCD Language	English	Edit

- 1. “Param Set” ->“Charger System” ->“Split System Internal Network Segment”
 - This parameter is the network segment used by the power cabinet upper controller to access the system LAN. The default value is "192.168.1. XX", and the other value is used by other systems.
- 2. “Param Set” ->“Charger System” ->“Power Cabinet Access OCPP Enable”
 - If the power cabinet needs to access the OCPP server, this parameter needs to be set to Enable, ‘OCPP Server End URL’ and ‘Charger ID’ also should set. See Section 7.3 for details.
- 3. “Param Set” ->“Charger System” ->“Dispenser Installed Total”
 - Set the total number of dispensers installed in the system.
- 4. “Param Set” ->“Charger System” ->“Charging Gun Installed Total”
 - Set the total number of charging guns that are installed in the system.
- 5. “Param Set” ->“Charger System” ->“Dispenser Type”
- 6. “Param Set” ->“PCU” ->“PCU Settings”
 - The PCU setting parameters are related to the power cabinet, and these parameters are very important. Some of these parameters must be set before the system runs.

PCU

PCU Settings [Edit](#)

Firmware Version	1.07	IMSU-X Hardware Version	A02
Boot Version	02.00	IMSU-X Startup Times	37
Door Open Alarm Enable	Disabled	SPD Alarm	Enabled
EPO Voltage Level	Alarm Normally Open	Total PM Grp Number	12
Total PM Number	20	Total DC output	5
Total Dispenser Number	4	Soft-start Time	1 seconds
AC Meter Ratio	150	AC Sleep Interval	0 min
Input Over Voltage Point	450 V	Input Under Voltage Point	310 V
Output Max Voltage	1050 V	Contactor Abnormal Judge Time	2 seconds
PM inlet overheating point	80 °C	PM outlet overheating point	93 °C
Busbar Lv1 overheating point	90 °C	Busbar Lv2 overheating point	120 °C
Temperature alarm hysteresis	5 °C	Busbar overheating curr lmt period	5 min
Busbar overheating curr lmt percent	80 %	Cooling Devices Type	Air cooling
AC Input Power Limit	10000 kW	Cabinet Fan Min Speed	25 %
Cabinet Fan Max Speed	100 %	Power Cabinet Fan Min Speed Temperature	40 °C
Power Cabinet Fan Full Speed Temperature	70 °C	Busbar Temperature Sensor Install	Not installed
PDU Inner Ring Enable	Yes	AC Input Single	No
Air cooled PC Outlet Over Temperature Lv1	90 °C	System Efficiency Setting	93 %
		Air cooled PC Outlet Over Temperature Lv2	100 °C


Parameter Name	Description	Value Range	Default Value	Remark
PCU Firmware Version	/	Read Only	/	
IMSU-X Hardware Version	/	Read Only	/	
Boot Version	Boot Loader Version	Read Only	/	
IMSU-X Startup Times	PCU Startup Times	Read Only	/	
Door Open Alarm Enable	/	Enable / Disable	Enable	
SPD Alarm Enable	/	Enable / Disable	Enable	
EPO Voltage Level	/	Alarm Normally Close / Alarm Normally Open	Alarm Normally Close	
Total PM Grp Number	The total number of power module groups in the power cabinet	0 ~ 16	8	must be manual set
Total PM Number	The total number of power modules in the power cabinet	0 ~ 32	16	must be manual set
Total DC Output Number	The total number of DC output busbar in the power cabinet	0 ~ 16	16	must be manual set
Total Dispenser Number	The total number of dispensers in the system	0 ~ 12	6	must be manual set
Soft-start Time	Soft start time of power module	0~255 S	1 S	
AC Meter Ratio	If the system has a AC meter, this parameter needs to be set	1~99999	160	
AC Sleep Interval	The time interval for the system to enter sleep mode from idle. If set to 0, it means the system will not enter sleep mode	0 ~ 255 S	0 S	
Input Over Voltage Point	If the input line voltage is greater than this value, an alarm will be triggered	0 ~ 2000 V	450 V	
Input Under Voltage Point	If the input line voltage is less than this value, an alarm will be triggered	0 ~ 2000 V	310 V	

Output Max Voltage	The maximum voltage that the power module can output	0 ~ 2000 V	1050 V	
Contactor Abnormal Judge Time	After controlling the contactor, determine the time interval for abnormal contactor status	0 ~ 255 S	2 S	
PM inlet overheating point	If the PM inlet temperature is greater than this value, an alarm will be triggered	0 ~ 255 'C	80 'C	
PM outlet overheating point	If the PM outlet temperature is greater than this value, an alarm will be triggered	0 ~ 255 'C	93 'C	
Busbar Lv1 overheating point	If the temperature of the busbar is greater than this value, LV1 alarm will occur. And the charging power will decrease	0 ~ 6553 'C	90 'C	
Busbar Lv2 overheating point	If the temperature of the busbar is greater than this value, LV2 alarm will occur. And the charging will stop	0 ~ 6553 'C	120 'C	
Temperature alarm hysteresis	When an over temperature alarm occurs, the alarm will only disappear if the temperature drops below the hysteresis value	0 ~ 255 'C	5 'C	
Busbar overheating current period	When the LV1 over temperature alarm of the busbar occurs, the cycle time of current limiting.	0 ~ 255 Min	5 Min	
Busbar overheating current percent	When the LV1 over temperature alarm of the busbar occurs, the percentage of current limiting.	0 ~ 100 %	80 %	
Cooling Devices Type	Cooling method of power cabinet	Water Cooling \	Air Cooling	
		Air Cooling		
AC Input Power Limit	System total AC power limit value.	0 ~ 65535 KW	10000 KW	
Cabinet Fan Min Speed	Minimum speed of rotation for power cabinet fan	0 ~ 100 %	25 %	
Cabinet Fan Max Speed	Maximum speed of rotation for power cabinet fan	0 ~ 100 %	100 %	
Power Cabinet Fan Min Speed Temperature	The starting temperature of the power cabinet fan	0 ~ 255 'C	40 'C	
Power Cabinet Fan Full Speed Temperature	There is a linear relationship between temperature and fan speed, and at this temperature, the fan speed will reach its maximum	0 ~ 255 'C	70 'C	

Busbar Temperature Sensor Install	Is the temperature sampling sensor of the busbar installed?	Not Install\ Install	Not Install	
AC Input Single	Is it a single AC input? If it is No, then the AC input is dual channel	No \ Yes	No	
PDU Inner Ring Enable	Installation Enable for Inner Ring Contactor of Power Distribution Unit	No \ Yes	No	
System Efficiency Setting	Assumed value of system efficiency. This value can be used to calculate the total available power on the DC side	0 ~ 100 %	93 %	
Air cooled PC Outlet Over Temperature Lv1	LV1 overheating point at the outlet of the power cabinet. If the temperature at the outlet of the power cabinet exceeds this value, the system will run at reduced power and alarm.	0 ~ 120 'C	90 'C	
Air cooled PC Outlet Over Temperature Lv2	LV2 overheating point at the outlet of the power cabinet. If the temperature at the outlet of the power cabinet exceeds this value, the system will become unavailable and alarm.	0 ~ 120 'C	100 'C	

- 7. "Param Set" -> "AC Cabinet" -> "AC Cube Setting" -> "AC Meter Enable"

[AC Cabinet](#)



- If the system is installed with an AC input meter, this value should be set to enable.
- 8. "Param Set" -> "AC Cabinet" -> "AC Contactor Setting"


AC Contactor Setting		Set	Cancel
AC Contactor Total Number	2		
2#PM Group AC Input Contactor	1		
4#PM Group AC Input Contactor	1		
6#PM Group AC Input Contactor	2		
8#PM Group AC Input Contactor	2		
10#PM Group AC Input Contactor	0		
12#PM Group AC Input Contactor	0		
14#PM Group AC Input Contactor	0		
16#PM Group AC Input Contactor	0		
1#PM Group AC Input Contactor	1		
3#PM Group AC Input Contactor	1		
5#PM Group AC Input Contactor	2		
7#PM Group AC Input Contactor	2		
9#PM Group AC Input Contactor	0		
11#PM Group AC Input Contactor	0		
13#PM Group AC Input Contactor	0		
15#PM Group AC Input Contactor	0		

- 'AC Contactor Total Number' is set to the actual number of AC contactors installed in the system. Next is the mapping relationship table between power module and AC input contactors. Non-existent power module groups write 0.
- Example: Standard ICE-600 Power Cabinet has 20 total Power Modules configured into 10 Groups of 2 and has 2 AC Input Contactors. Groups 1-5 are connected to the #1 AC Input Contactor, and Groups 6-10 are connected to the #2 AC Input Contactor. The settings required for proper operation are shown in the above image.

8.5) Reset and Test

8.5.1) System Self Check

- Ensure there are no vehicles connected to the charger and all charging cables are in their proper holsters. Close and lock all the equipment doors except for the Power Cabinet. Enter the PC-Upper Controller webpage (192.168.1.100) and initiate a system Self Check by going to **Manual Ctrl → PCU → Start System Self Check**.



- Pay attention to safety during the Self Check. After the Self Check starts, the power modules and contactors will perform a series of sequential actions until the end; The process takes about a few minutes. If the Self Check passes, there will be no alarms. If the Self Check does not pass, an alarm will prompt which items have not passed. Address the alarms as necessary.

9.) Description of Relevant Parameters

- The important setting parameters of the power cabinet and liquid-cooled charging terminal of the split charging system are described in the following table:
- input User Level and Password: Root


NO.	Parameter name	Default parameters	Remarks
1	CCU Work Mode	There is a dial switch on the back side of Pilot controller, which corresponds to terminal address # 1 or # 2...	At the same time, it also needs to correspond to the network TCP # address on the billing unit.
2	Liquid-cooled Connector Installing type	One dispenser can support up to one liquid cooling connector and can choose no/A gun or /B gun.	Select the connector installation position, and the corresponding 485 (# 1 or # 2) bus of the pilot controller will communicate with the IMEU2. Consistent with the system wiring.
3	Liquid-Bump Max Speed	Default maximum 50%	The pilot controller is sent to the IMEU2 board via RS485
4	Fan Speed Limit (Aux)	Default 100%	The small fan on the top side of the dispenser is used for cooling in the cabinet and running during charging.
5	Power Cabinet System Fan Full Speed Temperature	Default 131 F (55°C)	Pilot controller sent to IMEU2 offline via CAN
6	Power Cabinet System Fan Start up Temperature	Default 113 F (45°C)	Pilot controller sent to IMEU2 offline via CAN
7	Power Cabinet System Fan Startup Speed	40%	Starting speed of fan of power Cabinet system
8	Fan Speed Limit	100%	Power Cabinet system fan full speed limit.
9	Liquid-Bump Max Speed	100%	Max speed of liquid cooling unit oil pump
10	Liquid-Bump Startup Speed	20%	When the oil pump of the liquid cooling unit starts slowly, the initial speed.
11	Ring Nodes Total(connector)	Default 4	Note that it is actually consistent with the number of groups of modules. Even if there are only two guns, if there are four groups of modules, it needs to be set to 4.
12	Liquid Pump Full Sped Start up Temperature	Default 95 F (35°C)	The oil pump reaches the maximum speed when the oil temperature exceeds 35 degrees.

13	Liquid Pump Work Duration at Low Temperature	Default 1 min	Time to prevent solidification disturbance when oil temperature is too low.
14	Liquid Pump Pause Duration at Low Temperature	Default 2 min	
15	Max Output Current when liquid oil is in: Low Temp temperature	Default 300A	
16	When Gun Temp Over this point, act as Normal Gun	Default 149 F (65°C)	
17	Max Output Current when act as Normal Gun	Default 100A	
18	Cool Source EnvTemp High Point	Default 122 F (50°C)	
19	Cool Source EnvTemp Low Point	Default -13 F (-25°C)	
20	Liquid Oil High Pressure Alarm Point	Default 0.9Mpa	
21	Connector Over Temperature	Default 185 F (85°C)	
22	Connector Ultra Temperature	Default 203 F (95°C)	
23	Conn Recover from OverTemp Point	Default 149 F (65°C)	
24	Pressure Meter Range	Default 16	
25	Motor Pole Pair	Default 4	
26	Power Cabinet AC input Channels	Default 2	

10.) Power Distribution Strategy


10.1) Introduction to Power Nodes

- Each group of power modules is referred to as a group(s), corresponding to a charging gun (if the group is not connected to a charging gun externally, the group only performs power switching).



10 Nodes


- When charging begins, only the node corresponding to the charging gun provides output power. The node outputs power according to the demand of the dispenser. When the dispenser requests an increase in power, the node searches for available sub-nodes to parallelize with. When there is excess charging power, the root node will search for end-terminal sub-nodes and exit the parallelization.



- Using a 10-node system as an example, each node is connected to adjacent nodes on the left, right, and inside.

10.2) Scenario 1: Increasing Charging Power

- Group 1's left Group is Group 10, its right Group is Group 2, and its inside Group is Group 6.
- Group 1 serves as the root Group for charging. When the dispenser requests an increase in charging power, Group 1 will select Group 10 (left) as a sub-group. If the dispenser requests another power increase, Group 1 will select Group 2 (right) as a sub-group. And if the dispenser requests yet another power increase, Group 1 will select Group 6 (inside) as a sub-group. If, in this situation, the dispenser still requires a further increase in charging power, Group 1 will go through Group 10 (left of Group 1) to select Group 9 (left of Group 10) as a sub-group.
- Therefore, when there is a need to increase the charging power during the charging process, the root group will sequentially increase the power by selecting the left group, then the right group, and finally the inside group.
- If a group is found during the search process, but it is not an idle group (e.g., currently charging, charging as a child group, or experiencing a malfunction), then the algorithm will skip that group and continue searching for another available group. The goal is to find a suitable, idle group that can meet the changing requirements.





10.3) Scenario 2: Decreasing Charging Power

- When the required power decreases and remains below the current root group's maximum charging output power minus the maximum output power of the furthest end-terminal child group for a continuous duration of 30 seconds, the power allocation for the end-terminal group will be terminated.
- Using the example provided: Group 1 serves as the root group, and Groups 10, 2, 6, and 9 serve as child groups. At this stage, the maximum output power of the root group is the sum of the maximum output powers of Group 1, Group 10, Group 2, Group 6, and Node 9.

Since Group 9 is the furthest end-terminal group, when the charging power drops below the difference between the maximum output power of the root group and the maximum output power of group 9, and this condition persists for 30 seconds, Group 9 will exit and become an idle node. At this point, Groups 10, 2, and 6 become the new end-terminal child groups.


- When the charging power decreases further and meets the conditions for exiting a child group for a continuous duration of 30 seconds, the root group will exit the group with the lowest power among groups 10, 2, and 6 (for example, if group 10 has a maximum power of 60 kW, Group 2 has a maximum power of 60 kW, and Group 6 has a maximum power of 30 kW, then Group 6 will be exited).







- As shown in the diagram, when the required power decreases and meets the conditions for the furthest end- terminal group (Group 9) to exit for a continuous duration of 30 seconds, it will be prioritized for termination. Then, as the required power decreases further, with the new end-terminal groups being 10, 6, and 2, the group with the lowest output power will be prioritized for termination.

10.4) Scenario 3: Charging Initiated at Node Along the Power Path




- In this scenario, Group 1 serves as the root Group, and Groups 10, 2, 6, and 9 serve as child groups. At this moment, Group 10 initiates charging through its corresponding charging gun. As a result, Group 10 and all its child groups will exit the charging process and become idle groups. Group 10 will then function as a new root group, providing output power to the corresponding charging gun.





Note: A vehicle connected to group 10



Note: Group 10 is the new primary group

- In this situation, if the charging power is insufficient for the root Group 1, it will search for new child group by traversing through its child groups 6 and 2. Similarly, if the charging power of the root group 10 is insufficient, it will search for child nodes by exploring the left-side group 9 and the inner group 5. This scenario is similar to Scenario 1.

11.) User Operation

- The ICE-600 operation depends on its output connections: CCS or CHAdeMO. During the charging process, the Human Machine Interface (HMI), will give instructions and will signal different stages. These sequences are shown in this section.

11.1) Output Connector

- The ICE-600 is prepared to charge electric vehicles according to the charging systems mentioned. **Notes:** There is a coolant pipe inside the liquid cooling connector.
- CCS liquid cooling connector: Bending of the cable should be minimized to prevent restriction of the liquid coolant within the cable.
- See section 6.2 for more details


11.1.1) CCS1 and NACS Connector




11.2) Operation Instructions

- When the user starts the operation on the charging distributor, if all output connections are idle or the device allows DC charging, the HMI display will display the following screen:

CCS1+CCS1 Units




- Charging Steps
 - Plug the charging connector into the vehicle interface. UI main page display connector has "Plugged". Click "→Start" Button.




- Swipe the RFID or scan QR Code or use OTP by inputting the password to start the charging.




- Select Auto/Time/SOC/KWh charging strategy (Optional)



- On Waiting Start Charge.



- On Charging



- After the vehicle is fully charged, stop charging first, then unplug the charging connector.

11.3) Ethernet and OCPP Setting

- There are 2 standard parameters for back-end setting. Please get them from the back-end supplier.
 - Charger ID
 - OCPP Server End URL

Example 1: for a charge point with identity “CP001” connecting to a Central System with OCPP-J endpoint URL “ws://centralsystem.example.com/ocpp” this would give the following connection URL:

ws://centralsystem.example.com/ocpp/CP001

Figure 12.1 Example of OCPP-J 1.6 Spec

- Notes:** The protocol upper controller supports OCPP-J 1.6 and 2.0.1. Please refer to the OCPP official documents if you have any questions about the above 2 parameters or the protocol itself.

11.3.1) Connection Check


- If the above settings are done properly, you should see the  icon on screen (without reboot).
- Check the OCPP Platform for proper communication of the charger. Seeing the icon on the display screen only shows the charger is connected to the system but does not show the system sees the charger properly.

11.4) Network Setting


11.4.1) Router Set Up

This guide is intended to help configure the main Cradlepoint router inside the Power Cabinet for external communication. Log into the SSID of the Cradlepoint via the web browser.


- Click on “Devices” enter in the MAC address of the router that needs to be configured. Click on the device and it will bring you to the device page. If logging in via SSID you can skip this step.



- On the Device page click on “Configuration” then “Edit”. Drag Ethernet to the top of the list of “WAN Device Interface Profiles & Priority”.



- Once “Ethernet” is at the top of the list, under Connection Manager click on “Networking” and in the sub tab click “Local IP Networks”. Click on the first option check box and hit “Edit.”



- Click on “IPv4 settings” and make sure the IP address is the correct scheme needed for the Ice cube. This will ensure that all dispensers can properly communicate locally and externally to InControl. The IP address should be changed to 192.168.1.1.


R&D Editor

General Settings

IPv4 Settings

IPv6 Settings

Interfaces

Access Control

IPv4 DHCP

Multicast Proxy

IPv6 Addressing

Schedule

VRRP

STP

Wired 802.1X

Provide a unique IPv4 address range for this network.

IP Address: 192.168.100.1

Netmask: 255.255.255.0

IPv4 Routing Mode: NAT (default)

Always Proxy ARP: ☐

Cancel

Save

- Hit “save” then hit “Commit” at the bottom of the screen to update the Cradlepoint configurations.

11.4.2) Wireless Network Configuration

- First, check if your system is equipped with an external wireless router.
- This router is installed inside the Power Cabinet and is connected with the Network Switch with a RJ45 network cable. The router is usually pre-installed along with the charger before leaving factory, therefore the only thing needed to ensure it is operating properly.

11.4.3) Wired Network Configuration

- First, check if your system is equipped with an external wireless router.
- Connect the customer ethernet cable from their router LAN port to the WAN port of the Cradlepoint.

11.5) Charger Software Update

- The charger can update the firmware through OCPP or OEM backend remotely, or local update through USB drive to update the firmware of the upper controller and pilot controller.
- The following figure 11.1 software version is for reference only, the actual situation shall prevail.




Figure 11.1 Software Version

- CAUTION: It is imperative that the correct firmware be installed into each component. If the incorrect firmware for a component is installed, the component may require replacement and full reprogramming prior to operating properly. Please contact InCharge Support for assistance.

11.5.1) Upper Controller Update

- For upper controller's update, firstly power on the controller, and then plug the USB drive into the controller's USB inlet, and then go into the setting in "Manual Ctrl" --> "Charger System" -->

“Reboot System”, need to input “Soft Reset”, and waiting the automatic update finish, and then take off the USB disk. Check the software version as shown in Figure 11.2.





Figure 11.2 Software Version

11.5.2) Pilot Controller Update


- For pilot controller's update, firstly power on the controller, and then plug the USB disk into the controller's USB inlet. Then restart the system (disconnect the auxiliary switch, then close it again). Pay attention to the sound. After hearing three beeps, it means the upgrade is complete. You can pull out the USB drive. Check the software version as shown in Figure 11.3.




Figure 11.3 Software Version

Appendix 1) Engineering and Technical Parameters

- Reliable wall installation on both sides of the Power Cube. The front door should have a minimum gap of 1050mm to provide maintenance space.
- The lower part of the rear door of the Power Cube is air intake and the upper part is air outlet. A minimum gap of 1500mm should be provided to prevent hot air from flowing back into the inlet.




Power Cabinet Three Views




Power Cabinet Space Requirement

- The Slim Line Dispenser is reliable for wall installation, but it is recommended to leave at least 39.47 in (1000mm) distance. The front door should have a gap of at least 39.47 in (1000mm) to provide maintenance space.
- The Charging Dispenser has a right-side air inlet and a left side air outlet. A minimum gap of 39.47 in (1000mm) should be provided to prevent hot air from flowing back into the inlet.




Slim Line Dispenser Three Views




Slim Line Dispenser Spacing Requirements

The Micro Dispenser is reliable for Wall installation. The front door should have a gap of at least 23.62in (600mm)





Micro Dispenser Space Requirements

Appendix 2) Power Cabinet and Dispenser Schematic




Slim Line Dispenser:






Micro Dispenser



Appendix 3) System Electrical Connection Diagram



Attachment 2:

Method for removing CAN3 120 Ω Resistor from IMSU-X Monitoring

- Step 1: Unscrew the two screws on the left and right sides of the upper part of the IMSU-X monitoring board, and the upper monitoring board can be pulled out, as shown in the following figure



- Step 2: Find the matching resistor jumper cap on the monitoring board, as shown in the following figure.



- Step 3: Both jumper caps need to be changed from PIN 1 and 2 (with 120 Ω) to PIN 2 and 3 (without 120 Ω), as shown in the left and right figures.



- Step 4: Insert the upper control board back in and tighten the two fixing screws.

Appendix 4) Maintenance

1.) Maintenance Table


NO.	Position	Method	Tool	Maintenance cycle
1	AC input main breaker	Eyes check	/	2 months
2	Devices and connection points Main circuit devices (circuit breaker, AC contactor, DC contactor, DC fuse), copper bar, power module connector	Sound and Eyes check	Torque wrench	2 months
3	AC SPD	Eyes check	/	3 months
4	Charging plug	Eyes check	Brush	Daily
5	Cooling Fan and Filter cotton	Eyes check	Blower, Screwdriver Soft Brush Vacuum Cleaner	3~6 months
6	ESD	Eyes check	/	Daily
7	Alarm information check	Eyes check	/	Daily
8	Check all electrical connections	Sound and Eyes Check	Torque Wrench	12~24 months

2.) Maintenance Operation

2.1) AC Input Main Breaker

1.1 AC input main breaker

- 1) When the circuit breaker is in the closing state, press the insulation test knob or trip test button to test the insulation function or trip function of the circuit breaker.
- 2) After the circuit breaker is released, the recovery method is as follows: first turn the circuit breaker to the opening state, and then turn it to the closing state.






630A shell frame




2.2) Devices and Connection Points

- Check the connection points (circle in the picture) between the main circuit components (circuit breaker, AC contactor, DC contactor, fuse) and copper bar or cable, the connection points between copper bar and copper bar, and the connector of power module for burns or serious discoloration. If any are seen, please check the torque and connection according to point 2) and replace the damaged cable.
- Check whether the screw fixing torque mark is normal. If there is any deviation, please re-torque with a torque wrench and mark with a marker.


Types of connection points and similar structures		
Type A	Type B	Type C
		



AC Input side of Power Cabinet




DC Output side of Power Cabinet



DC side of Charging Dispenser

2.3) AC SPD

- Check the status window of SPD. If the window color changes from green to red, it indicates that SPD has been damaged, and the manufacturer will need to be contacted for replacement.




2.4) Charging Plug

- Check whether the charging plug is cracked or damaged. If so, please contact the manufacturer.
- Check whether the DC + and - terminals of the charging plug have obvious burning marks. If so, please contact the manufacturer for treatment.
- Use a brush to remove the dust on the surface of DC + and - terminals.


CCS1

DC+ and DC- terminals



CCS1 (Liquid cooling)

DC+ and DC- terminals



2.5 Cooling Fan and Filter Cotton

- Check the dust screen on both sides of the heat exchanger for dust.
- Use the fan to clean the dust on the dustproof net.
- According to the site environment, the dust net shall be effectively removed at least once every three to six months, and it shall be replaced once a year at most.


- Remove the dust screen with a screwdriver, and use a soft brush, blower and vacuum cleaner to remove the dust effectively.
- Use vacuum cleaner and soft brush cloth to effectively remove the sundries and dust in the cabinet.



Located on the bottom portion of the rear door

2.6) ESD

- Check the emergency stop cover plate. If the cover plate is damaged, please contact the manufacturer for replacement.




2.7) Alarm Information

- Click “?” In the upper right corner of the screen to view the alarm information.
- If there is alarm information, it should be handled immediately. If it cannot be handled, contact the manufacturer to handle.



Appendix 5) Error Codes and Possible Solutions



The screenshot shows the 'Active Alarm' tab in the InCharge software. The interface includes a top navigation bar with options like 'Detailed Info', 'Param Set', 'Manual Ctrl', and 'Charge Rec'. Below this is a table of active alarms with columns for Index, Level, Alarm Name, Source, Begin Time, and Status.

Index	Level	Alarm Name	Source	Begin Time	Status
1	MA	Server Comm Fail	Charger System	2000/01/01 20:00:48	Started
2	MA	One or more Rectifiers Alarm	Power Modules	2021/05/15 11:54:43	Started
3	CA	Mains Fail	CCU Group	2021/05/15 11:54:45	Started
4	CA	AC input Low Voltage	CCU Group	2021/05/15 11:54:45	Started
5	CA	System Not Available	Charger System	2021/05/15 11:54:47	Started

Table: Charger Alarms

NO.	Alarm ID	Alarm Name	Alarm Level	Description	Remark
1	1	System Not Available	CA	The system is out of service and charge is not allowed. This usually comes after other critical alarm (e.g. EPO pressed)	
2	2	System Disabled	MA	The system is out of service and charge is not allowed. This happens after system is set to 'In-operative' by service guy or back-end.	
3	4	Server Comm Fail	MA	Whether the network is not accessible or the connection between server and charger is broken. If the charger is supposed to be used offline this alarm can be ignored.	

4	5	All kWh Meter Not Installed	MA	All kWh meters are set to 'Not installed'. This means the system is not available. This alarm should not come with a normal charger unless you erase all the settings in controller Flash.	
5	6	CCU Comm Fail	CA	The communication between Upper controller and pilot controller failed. You need to check the RS-232-2 connection to eliminate it.	
6	7	EPO is pressed	CA	This alarm appears after someone pressed the EPO. Please reset the EPO when no emergency is existed to eliminate it.	
7	8	Door is opened	CA	The door should be closed.	
8	9	SPD alarm	CA	Check the SPD device and replace it.	
9	10	Mains Fail Alarm	CA	Check AC mains and the related contactor.	
10	11	Connector is disabled	MA	The specified connector is out of service and not allowed to charge. This happens after the connector is set to 'In-operative' by service guy or backend.	Connector A/B shall be specified
11	12	System over temp	MA	The temperature measurement from sensor is over the high limit point (default is 75 'C)	Note that this alarm does not stop/prohibit charge function
12	13	All Rectifier Failure	CA	This means system not available. Please check the work status of the power modules and make sure they work properly	
13	14	All Rectifier Comm Fail	CA	This means system not available. Please check the CAN wiring between power modules and pilot controller.	
				This means the specified connector will not be available. Please check the work status of the specified	Rectifier group (Dispenser A/B) shall be specified

14	15	Rectifiers Failure	CA	group of power modules and make sure they work properly.	
15	16	Rectifiers Comm Fail	CA	This means the specified connector will not be available. Please check the CAN wiring between power modules and pilot controller. Also, you may need check the dipswitches of the power module.	Rectifier group (Dispenser A/B) be specified
16	17	Insulation Comm Fail	CA	This means the specified connector will not be available. Check the RS-485 wiring between insulation detector and pilot controller.	
17	18	Output Shorted	CA	This is from Rectifiers after detected the internal circuit shorted	
18	19	Insulation Alarm	CA	This is from pilot controller after detected the insulation abnormal.	
19	20	PLC ComFail Alarm	CA	This is from pilot controller when the PLC communication is lost.	
20	21	Ground Fault	CA	This is from pilot controller after detected ground fault.	
21	22	AC Fail Alarm(for AC only)	CA	This is from pilot controller after detected AC connector input fails (DI)	
22	24	One or more Rectifiers Alarm	CA	This means one or more power modules in system has failure and you need to check/repair them.	
23	25	IMEU2(Liquid Control) Comm Fail	CA	This means the controller of the liquid connector cooling system has lost communication (RS485) to pilot controller. (Note: this is for the liquid connector in split charger system only.)	
				This means the controller of power controlling (inside the power cabinet) has lost communication (CAN) to charger main controller. (Note: this is	

24	26	IMEU2(Power Control) Comm Fail	CA	for the split charger system only.)	
25	27	Liquid Alarm-Pump Fail	CA	This means the pump has a failure in the liquid connector cooling system. (Note: this is for the liquid connector in split charger system only.)	
26	28	Liquid Alarm-High Temperature	MA	This means high temperature detected by liquid controller and the ongoing charging power will be derated. (Note: this is for the liquid connector in split charger system only.)	
27	29	Liquid Alarm-Over Temperature	CA	This means very-high-temperature detected by liquid controller and the ongoing charging will be derated or terminated. (Note: this is for the liquid connector in split charger system only.)	
28	30	Liquid Alarm-Temperature Sensor Fault	CA	This means the liquid controller detected that the temperature sensors have been all failed and the liquid connector may be disabled unless one of the sensors is recovered or repaired. (Note: this is for the liquid connector in split charger system only.)	
29	31	Liquid Alarm-Pump Pressure Abnormal	CA	This means the pump pressure has been detected as abnormal and the ongoing charging will be derated or terminated. (Note: this is for the liquid connector in split charger system only.)	
30	32	Liquid Alarm-Pump Oil Level Abnormal	CA	This means the pump oil level has been detected as abnormal and the ongoing charging will be derated or terminated. You need to check the oil. (Note: this is for the liquid connector in split charger system only.)	

31	33	AC input Over Voltage	CA	The AC mains voltage is higher than the max range which will cause the system run abnormally.	
32	34	AC input Low Voltage	CA	The AC mains voltage is lower than the min range which will cause the system run abnormally.	
33	36	CCU in Upgdate Process...	OA	This means the pilot controller is in upgrading process and system is temporarily disabled.	
34	301	CR CommFail	CA	Card Reader communication is failed. Check the RS-232 wiring between card reader and upper controller.	
35	401	kWhMeterCommFail	CA	The communication between upper controller and specified kWh meter is failed. This means the specified connector will be out of service and forbidden to charge. Please check the RS-485 wiring between the kWhMeter and upper controller.	
36	402	Sampled Invalid Current	CA	The measurement from the specified kWh meter is invalid. This usually happens with a reversed wiring for the current shunt.	
37	403	HeatExchangerCommFail	CA	The HeatExchanger is losing RS485 communication with Upper controller. This may be dangerous for the heatExchanger may have been physically damaged.	
38	404	U2 Comm Break	CA	There are two control boards, U1 and U2, inside the pilot controller, and their communication is abnormal. Please ensure that their control dial is correct and consistent, otherwise it may lead to charging failure	

39	405	Communication failure between CCU and PCU	CA	Communication failure between pilot controller and PCU, which may be due to abnormal CAN communication line connection or abnormal resistance value on the CAN bus (normally around 60 ohms)	
1. <i>CA</i> - Critical alarm <i>MA</i> - Major alarm <i>OA</i> - Observative Alarm					

Stop Reason Classification	Code	Description	Remark
Normal Stop	1	Normal Stop	Condition satisfied
	2	EV Request Stop	EV Request Stop
Charger Error	201	Parameter configuration failed	
	202	Charging Enable timeout	
	203	Abnormal volt of outside bus	
	204	Unable lock charging connector	
	205	Insulation inspection abnormally	
	206	Insulation inspection timeout	
	207	EV Relay Pull-In timeout	
	208	Require Curr Timeout	
	209	Remain time over stop	
	210	Ring fail alarm (reserved)	
	211	Communication with EV failed	
	212	Plugged connector timeout	
	213	Pre-Charging fault	
	214	DoorOpen	
	215	EPO	
	216	SPD	
	217	AllRectFail	
	218	MainsFailAlm	
	219	AIRectCommFail	

	220	E_LockFail	
	221	ConnectorOverTemp	
	222	OutputShortCircuit	
	223	PWM Failure	
	224	Ground Fault Detected	
	250	CR Comm Fail	
	251	kWhMeterComm Fail	
	252	CCU Comm Fail	
EV Error	301	Battery overvoltage	
	302	Battery undervoltage	
	303	Battery current deviation error	
	304	High battery temperature	
	305	Battery voltage deviation error	
	306	Charger Connector Lock Fault	
	307	Vehicle shift position	
	308	Error Status Noticed by EV	
	309	PLC Low Level Comm Fail	
	310	PLC High Level Comm Fail	
	311	PLC Authentication Timeout	
	312	PLC ParamDiscovery Timeout	
Canceled	401	Local Stop	
	402	Server Stop	
	403	Network fault	
	404	Reboot	
	405	DeAuthorized	
	406	One-Click Stop	
	407	Hard Reset	
	408	Soft Reset	
Other	501	Other	
	2000	PCU refuse invalid cmd	
	2001	PCU refuse request voltage too high	
	2002	refuse request current too high	
	2003	has non-usable PM	

PCU	2004	has no power distribute	
	2005	port fault	
	2006	PCU receive gun ID abnormal	
	2051-2109	PCU currently has an alarm	

Appendix 6) Torque Table

Screw specification (applicable scenario)	Normal torque (kgf.cm)	Normal torque (in-lbs)	Primary tightening tool	Secondary tightening tool
M4 (connection between DC contactor and copper bar)	12±10%	10.4±10%	Electric screwdriver	torque screwdriver
M5 (connection between air switch/lightning arrester and cable)	18--20	15.6±10%	Electric screwdriver	torque screwdriver
M5 (connection between copper bars and between cable and terminal)	30±10%	26±10%	Electric screwdriver	Cross screwdriver or torque screwdriver
M6 (connection between copper bars and between cable terminals)	45±10%	39.1±10%	Electric screwdriver	Cross screwdriver, torque screwdriver or wrench
M6 (connection between AC contactor and cable)	45±10%	39.1±10%	Electric screwdriver	Slot-type screwdriver and torque screwdriver
M6 (connection between DC contactor and copper bar)	45±10%	39.1±10%	Electric screwdriver	Torque screwdriver or wrench
M8 (connection between copper bars and between shunt and copper bar)	110±10%	95.4±10%	Electric screwdriver	Wrench, rocker arm or torque wrench
M8 (connection between DC contactor and copper bar)	100±10%	86.7±10%	Electric screwdriver	Wrench, rocker arm or torque wrench
M10 (connection between copper bars and between shunt and copper bar)	220±10%	191±10%	Electric screwdriver	Wrench, rocker arm or torque wrench
M12 (connection between copper bars)	390±10%	338.5±10%	Electric screwdriver	Wrench, rocker arm or torque

				wrench
Screw specification (applicable scenario)	Normal torque (kgf.cm)	Normal torque (in-lbs)	Primary tightening tool	Secondary tightening tool
M4 (connection between DC contactor and copper bar)	12±10%	10.4±10%	Electric screwdriver	torque screwdriver